

## AMUSEMENT RIDES – COMMON DIRECTIVES LISTING

Directive Code	Severity Text	Description
A000	Low	No Directives
A001	Low	OBTAIN OPERATING LICENCE FOR RIDE
A002	Low	PROVIDE DATA PLATE
A003	Low	HAVE UPDATED LOG BOOK ON SITE
A004	Low	FILE SAFETY BULLETIN ON SITE
A005	Low	IMPLEMENT ERECTION CHECKLIST
A006	Low	OBTAIN MANUFACTURERS/OWNERS SERVICE MANUALS
A007	Low	IMPLEMENT DAILY CHECKLIST & EXAMINATION PROCEDURES
A008	Low	PROVIDE ITINERARY (PORTABLE)
A009	Low	ENSURE MAINTNENANCE PROGRAM IN PLACE
A010	Low	PROVIDE OPERATOR/MAINTENANCE TRAINING
A011	Low	IMPLEMENT OPERATING PROCEDURE
A012	Medium	IMPLEMENT/PRACTICE EMERGENCY EVACUATION PROCEDURES & FIRST AID
A013	Low	OVER CONDITIONS - WORK REQUIRED - GENERAL
A050	High	PROVIDE ADEQUATE SUPPORT FOR THE INTENDED LOAD
A051	Medium	ENSURE LEVELLING AND ALIGNMENT
A052	High	PROVIDE BLOCKING AND SUPPORT JACKS
A053	Low	OVERALL CONDITIONS - WORK REQUIRED BLOCKING/FOUNDATION
A100	Medium	INSTALL/REPLACE ASSEMBLY PINS, BOLTS, & NUTS
A101	Medium	ENSURE TENSIONING DEVICES MEETS
A102	Medium	REPAIR/REPLACE/ADJUST GUYS & GUYS FASTENINGS
A103	High	ROPE SPLICING
A104	High	INSTALL/REPAIR WIRE ROPES
A105	Medium	REPAIR/REPLACE CABLES, CLAMPS, CHAIN
A106	Medium	INSTALL/REPAIR HYDRAULIC & AIR HOSES
A107	Low	OVER CONDITIONS - WORK REQUIRED STRUCTURAL
A151	High	REPAIR/REPLACE/ADJUST TRACK SYSTEM
A152	High	REPAIR/REPLACE/ADJUST SWEEPS
A153	Low	PROVIDE NDT (APPENDIX B) REPORT
A154	Medium	FIELD REPAIR WELDING
A155	Low	OVERALL CONDITIONS - WORK REQUIRED WELDING & STRUCTURE
A200	Medium	REPAIR/REPLACE/ADJUST PNEUMATIC CONTROLS

Directive Code	Severity Text	Description
A201	Medium	REPAIR/REPLACE/ADJUST PNEUMATIC SYSTEMS
A202	High	ENSURE SPEED OF RIDE COMPLYS WITH DESIGN SPECIFICATIONS
A203	High	REPAIR/REPLACE/ADJUST ANTI ROLLBACK DEVICES
A204	High	REPAIR/REPLACE/ADJUST BRAKING SYSTEM
A205	High	ENSURE CORRECT OPERATION OF EMERGENCY STOP
A206	Low	LEVEL PROTECTION DEVICE - ENSURE CORRECT OPERATION
A207	Low	SIGNAL SYSTEM FOR STARTING AND STOPPING - ENSURE CORRECT OPERATION
A208	Low	PROVIDE LIGHTING (LOADING AND UNLOADING AREA)
A209	Low	PROVIDE PASSENGER CONTROL (LOADING & UNLOADING)
A210	Low	PROVIDE SIGNAGE (RIDER RESTRICTIONS)
A211	High	ZONE CONTROL & BRAKING SYSTEM
A212	High	SWEEP BRAKES - ENSURE CORRECT OPERATION OF
A213	Low	OVERALL CONDITIONS - WORK REQUIRED CONTROL & RIDE OPERATION
A251	Low	PROVIDE PASSENGER CONTROL
A252	Low	INSTALL GUIDE FENCES & GATES
A253	Low	PROVIDE GUARD BARRIERS
A254	Medium	PROTECT AGAINST SHARP & PROTRUDING OBJECTS
A255	Medium	INSTALL SIGNS AND WARNING DEVICES
A256	Low	REPAIR/REPLACE PLATFORMS, CATWALKS, DECKING
A257	Low	REPAIR/REPLACE RAMPS, STAIRWAYS, STEPS
A258	Low	REPAIR/PROVIDE NON-SLIP SURFACES
A259	Medium	PROVIDE/REPAIR FIRE PREVENTION/PROTECTION & EMERGENCY LIGHTING
A260	Low	PROVIDE ADEQUATE CLEARANCE FOR RIDE
A261	Low	PROVIDE CLEARANCE FOR PASSENGER/PUBLIC
A262	High	PROVIDE CLEARANCE TO OVERHEAD POWER LINES
A263	High	FUEL STORAGE - ENSURE CORRECT
A264	Low	Overall conditions - Work required - Safe Guards.
A265	Low	xxx
A266	Low	xxx
A300	High	REPAIR/REPLACE CLUTCH AND BRAKE
A301	Medium	REPAIR/REPLACE DRIVE & ROAD WHEELS
A302	Medium	REPAIR/REPLACE HYDRAULIC, ELECTRIC MOTORS
A303	Medium	REPAIR/REPLACE/ADJUST V-BELTS AND DRIVE CHAIN
A304	Medium	REPAIR/REPLACE/ADJUST WIRE ROPE DRIVE CABLES
A305	Low	OVERALL CONDITIONS - WORK REQUIRED - DRIVE SYSTEM
A351	Medium	REPAIR/REPLACE RIDE CONTROLS
A352	High	REPAIR/REPLACE/PROVIDE ELECTRICAL BOXES
A353	Medium	REPAIR/REPLACE ELECTRICAL CABLES & WIRING LIGHTS

Directive Code	Severity Text	Description
A354	Medium	REPAIR/REPLACE/PROVIDE GROUNDING
A355	Low	PROVIDE WEATHER PROTECTION FOR ELECTRICAL DEVICES
A356	Low	OVERALL CONDITIONS - WORK REQUIRED - ELECTRICAL
A400	High	ENSURE CORRECT OPERATION: BUCKET BRAKE SYSTEMS
A401	Medium	BODY CONDITION (ENCLOSURE, SEATS, ETC.) - REPAIR/REPLACE
A402	High	PROVIDE/REPAIR/REPLACE LOCK & SAFETY PINS
A403	Medium	PROVIDE PADDING
A404	High	REPAIR/REPLACE/ADJUST SAFETY RESTRAINTS (LAP BARS, SAFETY BELTS, ETC.)
A405	Medium	SEAT ANCHORS AND SPINDLES
A406	Medium	PROTECT AGAINST SHARP AND PROTRUDING OBJECTS
A407	High	REPAIR/REPLACE/ADJUST WHEELS AND BOGIES
A408	Low	OVERALL CONDITIONS - WORK REQUIRED - CARRIER
A409	Low	xxx
A410	Low	xxx
A996	Medium	Reviewed Operation Log and maintenance records
A997	Low	-
A998	Medium	-
A999	High	-

Total Operable ERA Directive Lists: 88