

Date	Device Type	Rationale
01-Jun	LPPD Venc Hydro	Lift runs down uncontrolled for approximately 7 feet and will not respond to up command or emergency stop button
02-Jun	LPPD	Low Pressure switch not working
02-Jun	Passenger Hydro	The emergency alarm bell and phone do not function.
03-Jun	LPPD Roped Hydro	Alarm Bell in Lift not functioning when normal building power has been removed from control circuit.
03-Jun	LPPD Vert Encl	Alarm bell and emergency light not functioning in the event of power failure.
03-Jun	Escalator	Skirt switches not adjusted correctly.
03-Jun	Escalator	Skirt switches not adjusted correctly, excessive handrail cracking
03-Jun	Passenger Traction	The emergency phone did not function
07-Jun	LPPD Vert	Emergency Operation does not function, no alarm bell operating.
07-Jun	Escalator	Large chunk of the step tread is missing and the top and bottom vertical combplate impact devices failed to activate
07-Jun	LPPD Stair pltfm	The underpan touch sensitive switches only function for a portion of the underpan surface area.
07-Jun	Passenger Traction	Restrictor not functioning
07-Jun	Passenger Traction	Damage to idler sheave due to the governor rope cutting into hardware
08-Jun	Passenger Hydro LU	The emergency phone is not working and there is no alarm bell
08-Jun	LPPD Vert. Encl.	The safeties did not stop the car during safety test.
08-Jun	LPPD Vert. Encl.	The lift breaks traction in the down direction with empty car and alarm bell not working
08-Jun	LPPD-Vertical Encl	The car safeties did not mechanically engage during drop tests
08-Jun	Manlift	The emergency alarm bell and phone do not function.
08-Jun	Manlift	The emergency alarm bell and phone do not function.
10-Jun	Passenger Hydro	The Seal for the Pressure Relief Valve is missing and the 2021 Category 1 test for the Valve seal is signed off as completed successfully.
10-Jun	Escalator	Broken Step Treads
10-Jun	Escalator	Broken Step Treads
10-Jun	Escalator	Broken step treads.
11-Jun	Passenger Traction	Car door detector not operating as intended.
14-Jun	LPPD Vert Encl	The hydraulic cylinder is not fastened at the bottom to the pit steel allowing it to move.
14-Jun	LPPD Vert Encl	The car could be run with the top and bottom hall door locks not physically locked
14-Jun	LPPD Vert Encl	The car would still leave the floor when the bottom landing hall door is in an open position and The safeties failed to operate as required.
14-Jun	LPPD Stair Platform	The pressure plate on the under side of the lift and the switch for the folding were not functioning.
15-Jun	Passenger Hydro	Unsafe car-top inspection operation.
15-Jun	LPPD Vert Encl	The Emergency Operation is not functioning in the event of building power failure. No Emergency light or alarm bell.
16-Jun	LPPD Vroped Hydro	Anitcreep failed to operate
16-Jun	Passenger Roped Hydro	A slack rope switc failed to operate
16-Jun	LPPD Vert Encl	Unit loses traction and Alarm bell not working
16-Jun	Freight Traction	Safety Operating plunger does not function/operate
17-Jun	Manlift Power type	Safety Operating Switch does not function
21-Jun	Freight Traction	Emergency Alarm Bell and Communications not working
24-Jun	Escalator	One of the skirt switches were not functioning properly and there were broken step treads.
24-Jun	Escalator	Broken step treads and combplate
24-Jun	Escalator	Broken step treads.
25-Jun	LPPD Vert Encl	Emergency Alarm not functioning
28-Jun	Escalator	Step upthrust does not mechanically actuate/ Bottom left skirt switch doesn't work.upper handrail inlet switches don't work.
28-Jun	Escalator	Both upper handrail inlet switches and the bottom left handrail inlet switch do not work. The step level device is damage/bent. Step to step clearance is measured at 10mm
30-Jun	Escalator	Broken Drive Chain Device continues to activate in down direction and actuating cable is being held with tie wrap.