

Date	Device Type	Rationale
01-Jun	Escalator	Handrail damage creating pinch point / main line wiring damaged
02-Jun	Stair Chair	Chair Safety Slack Rope Switch does not open safety circuit when Safety is mechanically applied.
02-Jun	LPPD	Car safety would not engage
02-Jun	Passenger Traction	Car Door Restrictor not functioning
02-Jun	Freight Hydro	Rear gate switch not working
03-Jun	LPPD Roped Hydro	Failure of Anti-creep
06-Jun	LPPD Vert Enclosed	Hoist rails are movable by hand in hoistway from hoistway wall.
06-Jun	LPPD Vert Enclosed	Loose Fasteners on Deflector sheaves and through bolts in hoistway and Lift Machine room.
		Registering Floor M Car Call causes contactor buzzing in Lift Controller and will not register Car Call
		Lift drifts through Machine Brake unloaded in the down direction. Inspector able to manually move brake disc
06-Jun	LPPD Vert Enclosed	Safties failed to mechanically engage and trip SOS switch
07-Jun	Passenger Traction	Missing Governor Seal on Overspeed adjustment rod.
07-Jun	Passenger Hydro	The car door restrictor did not work below the top floor.
07-Jun	Freight Traction	Missing seal on Governor tension spring
07-Jun	LPPD Traction	Emergency alarm bell not working.
08-Jun	Escalator	The unit has a broken step tread and the handrail drive system is not working properly sprockets skipping on the chain drive.
08-Jun	Escalator	The anti reversal device is not functioning correctly.
09-Jun	Escalator	Damaged skirt, SSPI test failed,CAT 1 test not done, excessive gap between comb plate and skirt, and demarcation lights not hooked up
09-Jun	Escalator	Skirt are damage, cat 1 testing 18 month past due, sagging switch not tripping, demarcations lights not hooked up, SSPI fail not completed excessive gap between cmlt and skirt at top end
13-Jun	Passenger Traction	Emergency Phone/Alarm not working
14-Jun	Passenger Traction	Car Door Restrictor not functioning
15-Jun	Passenger Traction	Service Provider has installed a Rope Fastener incorrectly on Car Governor Rope that will prevent Car Safeties from applying when required.
16-Jun	Passenger Traction	Car Door Gib guide is off Gib Bracket on bottom of Door and only one floating machine screw is guiding Car Door in Sill.
17-Jun	Passenger Traction	Car Door Restrictor not functioning
20-Jun	Escalator	Escalator runs while the combplate teeth are above and not meshed with the step treads.
20-Jun	Escalator	Escalator runs while the combplate teeth are above and not meshed with the step treads.
20-Jun	Escalator	Skirt and Combplate swithes not working
20-Jun	Escalator	Upper combplate impact switch not working
20-Jun	MRL Passenger Traction	Plank switch not working
21-Jun	Escalator	The escalator runs with the combplate teeth above the step treads (not meshed)
		The brake is under torque as per manufacturers specification and the slide exceeds the maximum manufacturers specification
21-Jun	Escalator	Lower combpalte switch and upper R skirt switch not working and there is a crack in lower R step track
21-Jun	Manlift Power Type	Phone is not working inside Manlift and Manlift is not equipped with an Alarm Bell.
22-Jun	Manlift Power Type	Hall Doors are able to open when Manlift is not present on Floors 1 and 3.
22-Jun	Passenger Traction	Drive Machine Brake is missing connecting parts components affecting deceleration.
		Corrosion and material loss found on Machine Room equipment and Pit equipment.
		Pit has water present and Pit equipment is corroded.
		Elevator Machine Room has pigeon excrement all over equipment and needs to be cleaned and maintained.
22-Jun	Passenger Traction	Drive Machine is missing connecting parts/components affecting brake deceleration.
		Emergency Alarm Bell is not functioning inside Elevator.
		Car Governor Jaw Switch is not functioning.
22-Jun	LPPD Stair Pltfm	The slack rope switch does not mechanically actuate.
22-Jun	Manlift Power Type	Hall Doors are able to be opened when Manlift is not present on Floors #2,#3 and #5.
23-Jun	Manlift Power Type	Hall Doors on Floors #2, #3, #4 open when Manlift is not present at landing.
		Emergency Alarm Bell does not function with normal power supply removed from control circuit.
23-Jun	Passenger Traction	Governor rope damaged (kinked/frayed)
24-Jun	Passenger Traction	Car Door Restrictor not functioning
27-Jun	Escalator	The bottom left handrail inlet switch does not mechanically actuate.
27-Jun	Passenger Hydro	Failure of the pressure switch
27-Jun	Passenger Traction	Spring between the crosshead and deadend hitch out of adjustment
28-Jun	Type B Freight	The low pressure switch does not mechanically change state.
29-Jun	Passenger Traction	Car Door Restrictor not functioning
29-Jun	Passenger Traction	Car Door Restrictor not functioning
30-Jun	Escalator	Damaged handrail with excessive pinch points
30-Jun	Escalator	Damaged handrail, crack on step track, skirt and combplate switches not working